

DVD's and VHS Guide

1. **Turn on projector** using the **ON** button with the remote provided. The projector takes approx 1 minute to warm up. To determine if the projector is booting up properly check the green status indicator light located underneath the unit. A blinking green or steady light indicates the projector is operating normally. The projector **SOURCE** should be on **Video**. *Change volume using the projector remote*
2. **Check the Power Amp** located in the lower right corner of the lectern. The red glowing toggle switch should indicate that the unit is working properly. If no red light is present, hit the switch to turn on power. **Under no circumstances should the power amp ever be turned off.**
3. **Turn on the DVD COMBO UNIT** using the **ON** button located on the left side of the Unit. Select DVD or VHS mode using the two circular buttons located toward the center of the UNIT. Insert preferred media as normal.

Trouble Shooting

If there is no video projected on the screen try changing the source using the remote by pressing either the **SOURCE / RGB Button** or using the **Video Button**.

If the source of the projector is, correct and no video is being projected check the **Mode Selector** located on the equipment rack or on top of the lectern toward the back. The system should be on computer mode. Press the computer button on the mode selector (shaped like a computer tower).

If the Lectern Unit is not powering up, check to see if its power cord is plugged in to the wall jack behind the unit (large black input)

DO NOT ATTEMPT TO REPAIR EQUIPMENT YOURSELF

For additional assistance, remotes, etc. please call Media Services at ext. 303 or after 4:00pm ext. 479 using a telephone located in the hallway.